


# **REPAIR PARTS**

### **GKS9 Single Stage PSC Upflow Furnace**

GKS90453BXAA GKS90453BXAB GKS90453BXAC GKS90703BXAA GKS90703BXAB GKS90703BXAC GKS90703BXAD GKS90703BXAE GKS90704CXAA GKS90704CXAB GKS90704CXAC GKS90904CXAA GKS90904CXAB GKS90904CXAC GKS90904CXAD GKS90904CXAE GKS90905DXAA GKS90905DXAB GKS90905DXAC GKS91155DXAA GKS91155DXAB GKS91155DXAC GKS91155DXAD



This manual is to be used by qualified technicians only.

This manual replaces RP-410E.

© 2006-2008 Goodman Manufacturing Company, L.P.  $\Diamond$  5151 San Felipe, Suite 500  $\Diamond$  Houston, TX 77056

### **Important Information**

#### Index

Functional Parts List	 3
Illustration and Parts	4 - 11

Views shown are for parts illustrations only, not servicing procedures.

Rev. F: Added model GKS90703BXAE and ACCESS DOOR GASKET (121).

#### **Text Codes:**

AR - As Required NA - Not Available NS - Not Shown 00000000 - See Note

QTY - Quantity Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model Example (M1) (If M Code not shown, then part is used on all Models)

#### **Expanded Model Nomenclature:**

Example

M1 - Model#1

M2 - Model#2

M3 - Model#3

Goodman Manufacturing Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Goodman Manufacturing Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Goodman Manufacturing Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact: Consumer Affairs Department Goodman Manufacturing Company, L.P. 7401 Security Way Houston, Texas 77040 877-254-4729-Telephone 713-863-2382-Facsimile For assistance outside the U.S.A. contact: International Division
Goodman Manufacturing Company, L.P.
7401 Security Way
Houston, Texas 77040
713-861-2500-Telephone
713-863-2382-Facsimile

#### **Functional Parts**

#### Part

#### No: Description:

B1340024S BLOWER MOTOR 1/2 HP, 4 SP, 6 PL (M9, M10, M11, M12, M13, M14, M15, M16) BLOWER MOTOR 1/3 HP, 4 SP, 6 PL (M1, M2, 0131F00020 M3, M4, M5, M6, M7, M8) BLOWER MOTOR 3/4 HP, 4 SP, 8 PL (M17, 10759415S M18, M19, M20, M21, M22, M23) CAP125000370VAS CAPACITOR 12.5/370V (M1, M2, M3, M4, M5, M6, M7, M8) CAP150000370VAS CAPACITOR 15/370V (M17, M18, M19, M20, M21, M22, M23) CAPACITOR 20/370V (M9, M10, M11, M12, CAP200000370VAS M13, M14, M15, M16) 0130F00010 FLAME SENSOR 0130F00005S IGNITION BOARD, HSI INTEGRATED 20165703S IGNITOR B1370818 INTERLOCK SWITCH 10123535 MANUAL RESET LIMIT (M1, M2, M3, M4, M5, M6, M7, M8, M9, M10, M11, M12, M13, M14, M15, M16, M17, M18, M19) MANUAL RESET LIMIT 10123533 20197312 PRESSURE SWITCH-LIGHT BLUE (M1, M9, M17) 0130F00002P PRESSURE SWITCH-OLIVE (M16) 20197310 PRESSURE SWITCH-ORANGE (M12, M20) 0130F00004 PRESSURE SWITCH-RED (M4, M18, M19) 0130F00001P PRESSURE SWITCH-SUNGOLD (M2, M3, M5, M6, M7, M8, M10, M11, M13, M14, M15, M21, PRIMARY LIMIT-BLUE (M4, M5, M6, M7, M8, 20162903 M9, M10, M11, M17, M18, M19) PRIMARY LIMIT-TEMPERATURE CONTROL 20162904 (M1, M2, M3, M12, M13, M14, M15, M16) PRIMARY LIMIT-WHITE (M20, M21, M22, M23) 20162906 B1141605 TRANSFORMER 120V TO 24V, 40 VA


#### **Expanded Model Nomenclature**

M1 - GKS90453BXAA M2 - GKS90453BXAB M3 - GKS90453BXAC M4 - GKS90703BXAA M5 - GKS90703BXAB M6 - GKS90703BXAC M7 - GKS90703BXAD M8 - GKS90703BXAE M9 - GKS90704CXAA M10 - GKS90704CXAB M11 - GKS90704CXAC M12 - GKS90904CXAA M13 - GKS90904CXAB M14 - GKS90904CXAC M15 - GKS90904CXAD M16 - GKS90904CXAE M17 - GKS90905DXAA M18 - GKS90905DXAB M19 - GKS90905DXAC M20 - GKS91155DXAA M21 - GKS91155DXAB M22 - GKS91155DXAC M23 - GKS91155DXAD

#### **SPECIAL PARTS**

IO-300E INSTALLATION INSTRUCTIONS
IO-669 KIT INSTRUCTIONS-HUMIDIFIER
0161F00000P NAMEPLATE, GOODMAN
RP-410F REPAIR PARTS MANUAL
IO-661 SPECIAL INSTRUCTIONSMASSACHUSETTS
0270F00399 STANDPIPE BAG ASSY
HI-115A USERS MANUAL

### Cabinet



### **Cabinet**


Ref. Part


Ref. Part No: No: No: No: **Description: Description:** 

.,	110.	cacription.	No. No. Description
Imag	ge 1:		Expanded Model Nomenclature
21	0161F00000P	NAMEPLATE, GOODMAN	M1 - GKS90453BXAA
81	20201902	DRAIN HOSE	M2 - GKS90453BXAB
111	20179308	GASKET (QTY 2)	M3 - GKS90453BXAC
121	20194605	GASKET (M1, M2, M3, M4, M5, M6, M7, M8)	M4 - GKS90703BXAA
121	20194606	GASKET (M9, M10, M11, M12, M13, M14, M15, M16)	M5 - GKS90703BXAB M6 - GKS90703BXAC
121	20194607	GASKET (M17, M18, M19, M20, M21, M22, M23)	M7 - GKS90703BXAD
191	0121F00072DGS	ACCESS DOOR (M1, M2, M3, M4, M5, M6, M7, M8)	M8 - GKS90703BXAE
191	0121F00073DGS	ACCESS DOOR (M9, M10, M11, M12, M13, M14, M15, M16)	M9 - GKS90704CXAA
191	0121F00074DGS	ACCESS DOOR (M17, M18, M19, M20, M21, M22, M23)	M10 - GKS90704CXAB M11 - GKS90704CXAC
201	0121F00069DGS	BLOWER DOOR (M1, M2, M3, M4, M5, M6, M7, M8)	M12 - GKS90904CXAA
201	0121F00070DG	BLOWER DOOR (M9, M10, M11, M12, M13, M14, M15, M16)	M13 - GKS90904CXAB M14 - GKS90904CXAC
201	0121F00071DG	BLOWER DOOR (M17, M18, M19, M20, M21, M22, M23)	M15 - GKS90904CXAD
281	B1392139	VIEW PORT BUSHING-BLOWER DOOR	M16 - GKS90904CXAE
291	11104002	VIEW PORT BUSHING-ACCESS DOOR (M1, M2, M4, M5, M9, M10, M12, M13, M17, M18, M20, M21)	M17 - GKS90905DXAA M18 - GKS90905DXAB
291	B1392139	VIEW PORT BUSHING-ACCESS DOOR (M3, M6, M7, M8, M11, M14, M15, M16, M19, M22, M23)	M19 - GKS90905DXAC M20 - GKS91155DXAA
311	22320001	DECK GASKET (M1, M2, M3, M4, M5, M6, M7, M8)	M21 - GKS91155DXAB
311	22320002	DECK GASKET (M9, M10, M11, M12, M13, M14, M15, M16)	M22 - GKS91155DXAC
311	22320003	DECK GASKET (M17, M18, M19, M20, M21, M22, M23)	M23 - GKS91155DXAD
451	M0501301	PIPE GROMMET	
491	M0570808	BUTTON PLUG (QTY 4)	
501	M0570806	PLUG-BUTTON	
511	M0570807	BUTTON PLUG	
601	A4691701	GROMMET (QTY 2)	
621	M0310345	BUTTON PLUG (QTY 2)	
741	B1392104	UNIVERSAL BUSHING UB 875 (QTY AR)	
NS	0270F00399	STANDPIPE BAG ASSY	
NS	0159F00003	WIRING HARNESS	
Imag	ge 2:		
12	10254303	RUBBER COUPLING	
22	0163M00049	HOSE CLAMP (QTY 2)	
32	M0119207	HOSE CLAMP	
62	20201901	DRAIN HOSE	
72	20201802	DRAIN TUBE (QTY 2)	
82	20171701	DRAIN TRAP	
112	20214203	DRAIN ANGLE	
	M0119205	HOSE CLAMP (QTY 3)	
142	1010 1 1 92 0 3	TIOGE GET WIT (QTT 3)	

## **Blower Assembly**

lmage 1






### **Blower Assembly**


Ref. Part
No: No: Description: Ref. Part
No: No: Description: Description:

No:	No: De	escription:	No: No:	Description
Imag	e 1:		Expanded Model N	omenclature
41	B1368047A	BLOWER WHEEL 10 X 10 (M9, M10, M11, M12, M13, M14, M15, M16)	M1 - GKS90453B	XAA
41	B1368058S	BLOWER WHEEL 10 X 8 (M1, M2, M3, M4, M5, M6, M7, M8)	M2 - GKS90453BX	
51	764741F	BLOWER BLOCK-OFF 10 X 10 (M9, M10, M11, M12, M13, M14, M15, M16)	M4 - GKS90703B	XAA
51	764740F	BLOWER BLOCK-OFF 10 X 8 (M1, M2, M3, M4,	M5 - GKS90703BX	
161	CAP125000370VAS	M5, M6, M7, M8)  CAPACITOR 12.5/370V (M1, M2, M3, M4, M5, M6, M7, M8)	M7 - GKS90703BX	
161	CAP200000370VAS	M7, M8)  CAPACITOR 20/370V (M9, M10, M11, M12, M13,	M9 - GKS90704C	XAA
181	B1340024S	M14, M15, M16) BLOWER MOTOR 1/2 HP, 4 SP, 6 PL (M9, M10,	M10 - GKS907040 M11 - GKS907040	
181	0131F00020	M11, M12, M13, M14, M15, M16) BLOWER MOTOR 1/3 HP, 4 SP, 6 PL (M1, M2, M3,	M12 - GKS909040	CXAA
191	0271F00003PS	M4, M5, M6, M7, M8) BLOWER HOUSING ASSY 10 X 10 (M9, M10, M11,	M13 - GKS909040 M14 - GKS909040	
191	0271F00000P	M12, M13, M14, M15, M16)  BLOWER HOUSING ASSY 10 X 8 (M1, M2, M3, M4,	M15 - GKS909040	
231	M0250558	M5, M6, M7, M8)  TC SCREW (M1, M2, M3, M4, M5, M6, M7, M8, M9,	M16 - GKS909040 M17 - GKS90905E	
		M10, M11, M12, M13, M14, M15, M16)	M18 - GKS909050	
401	0130F00005S	IGNITION BOARD, HSI INTEGRATED	M19 - GKS90905E	
461	0121F00025P	CONTROL BRACKET	M20 - GKS91155	
481	B1141605	TRANSFORMER 120V TO 24V, 40 VA	M21 - GKS91155E	
Imag	e 2:		M22 - GKS91155	
22	D6723311S	BLOWER WHEEL (M17, M18, M19, M20, M21, M22, M23)	M23 - GKS91155E	DXAD
32	C6121807	BLOWER CUT-OFF (M17, M18, M19, M20, M21, M22, M23)		
82	20175101	BLOWER SIDE RAIL (M17, M18, M19, M20, M21, M22, M23)		
142	10441601	MOTOR MOUNT BAND (M17, M18, M19, M20, M21, M22, M23)		
152	10441501	MOTOR MOUNT ARM (M17, M18, M19, M20, M21, M22, M23)		
162	CAP150000370VAS	CAPACITOR 15/370V (M17, M18, M19, M20, M21, M22, M23)		
182	10759415S	BLOWER MOTOR 3/4 HP, 4 SP, 8 PL (M17, M18, M19, M20, M21, M22, M23)		
192	0271F00048	BLOWER HOUSING ASSY 11 X 10 (M17, M18, M19, M20, M21, M22, M23)		
232	M0221461	TC SCREW (M17, M18, M19, M20, M21, M22, M23)		
252	M0267144	MACHINE SCREW (M17, M18, M19, M20, M21, M22, M23)		
282	M0282015	KEPS NUT (M17, M18, M19, M20, M21, M22, M23)		
602	A4002702	BLOWER MOTOR GROMMET (M17, M18, M19, M20, M21, M22, M23)		

### Chassis

Image 1






### **Chassis**

Ref. No:	Part No:	Description:		Part No:	Des	cription:
Image	e 1:		Imag	e 1:		
11	0121F00050DGS	BASE PAN (M1, M2, M3, M4, M5, M6, M7, M8)	611	0163M0004	19	HOSE CLAMP (QTY 2)
11	0121F00051DG	BASE PAN (M9, M10, M11, M12, M13, M14, M15,	741	B1392104		UNIVERSAL BUSHING UB 875 (QTY 2)
	04045005050	M16)	791	20194608		GASKET (QTY 2)
11	0121F00052DG	BASE PAN (M17, M18, M19, M20, M21, M22, M23)	811	20194605		GASKET (M1, M2, M3, M4, M5, M6, M7, M8)
31	0121F00043	BLOWER DECK (M1, M2, M3, M4, M5, M6, M7, M8)	811	20194606		GASKET (M9, M10, M11, M12, M13, M14, M15,
31	0121F00045	BLOWER DECK (M9, M10, M11, M12, M13, M14, M15, M16)	011	20104607		M16)
31	0121F00048	BLOWER DECK (M17, M18, M19, M20, M21, M22, M23)	811 NS	20194607 C6415909		GASKET (M17, M18, M19, M20, M21, M22, M23) HEAT EXCHANGER INSULATION (M17, M18, M20, M21, M22, M23)
41	0154F00000P	COIL GASKET (M1, M2, M3, M4, M5, M6, M7, M8)	NC	C644E040		M20, M21, M22, M23)
41	0154F00001P	COIL GASKET (M9, M10, M11, M12, M13, M14, M15, M16)	NS	C6415910		HEAT EXCHANGER INSULATION (M1, M2, M3, M4, M5, M6, M7, M8)
41	0154F00002P	COIL GASKET (M17, M18, M19, M20, M21, M22, M23)	NS	C6415911		HEAT EXCHANGER INSULATION (M9, M10, M11 M12, M13, M14, M15, M16)
81	20273208	BACK PANEL (M1, M2, M3, M4, M5, M6, M7, M8)	NS	0164M0000	)2	PRESSURE SWITCH HOSE
81	20273210	BACK PANEL (M9, M10, M11, M12, M13, M14, M15,	Imag			
		M16)	352	10861101		AUXILIARY LIMIT BRACKET
81	20273212	BACK PANEL (M17, M18, M19, M20, M21, M22, M23)	362	10123519		AUXILIARY LIMIT (M20, M21, M22, M23)
101	0121F00018P	DECK RAIL (M1, M2, M3, M4, M5, M6, M7, M8)	362	10123535		MANUAL RESET LIMIT (M1, M2, M3, M4, M5, M6 M7, M8, M9, M10, M11, M12, M13, M14, M15, M1 M17, M18, M19)
101	0121F00019P	DECK RAIL (M9, M10, M11, M12, M13, M14, M15, M16)	Expa	ınded Mode	l Nomen	
101	20191303	DECK RAIL (M17, M18, M19, M20, M21, M22, M23)	M1	- GKS9045	3BXAA	7
111	0270F00001PS	TOP COVER ASSY (M9, M10, M11, M12, M13, M14, M15, M16)		- GKS9045; - GKS9045;		
111	0270F00002PS	TOP COVER ASSY (M17, M18, M19, M20, M21, M22, M23)	M4	- GKS9070	ЗВХАА	
111	0270F00100PS	TOP COVER ASSY (M1, M2, M3, M4, M5, M6, M7, M8)		- GKS9070: - GKS9070:		
121	20191602	SIDE RAIL (M1, M2, M3, M4, M5, M6, M7, M8)	M7	- GKS9070	3BXAD	
121	20191603	SIDE RAIL (M9, M10, M11, M12, M13, M14, M15, M16)		- GKS9070		
121	20191604	SIDE RAIL (M17, M18, M19, M20, M21, M22, M23)	M10	) - GKS907	04CXAB	
141	0121F00092DGS	SIDE PANEL LH	M1 <sup>2</sup>	1 - GKS9070	04CXAC	:
151	0121F00090DGS	SIDE PANEL RH	M12	2 - GKS9090	04CXAA	
221	B1370818	INTERLOCK SWITCH	M13	3 - GKS9090	04CXAB	
231	22309501	FLUE PIPE	M14	4 - GKS9090	04CXAC	:
241	20171802	ELBOW	M15	5 - GKS9090	04CXAD	•
271	22307501S	ID BLOWER	M16	6 - GKS909	04CXAE	
281	20049701	FA COUPLING	M17	7 - GKS9090	05DXAA	
311	10736102	HIGH VOLTAGE BOX (M1, M2, M4, M5, M9, M10, M12, M13, M17, M18, M20, M21)		3 - GKS9090 9 - GKS9090		
331	10736201	COVER, HIGH VOLTAGE BOX (M1, M2, M4, M5, M9, M10, M12, M13, M17, M18, M20, M21)	M20	) - GKS911	55DXAA	
391	M0275521	PLASTIC SEALER (M20, M21, M22, M23)		1 - GKS911		
411	0161F00004	JUNCTION BOX-PLA (M3, M6, M7, M8, M11, M14, M15, M16, M19, M22, M23)		2 - GKS911! 3 - GKS911!		
421	A4554801	SNAP BUSHING (M1, M2, M4, M5, M9, M10, M12, M13, M17, M18, M20, M21)				_
431	0161F00005	JUNCTION BOX-LID (M3, M6, M7, M8, M11, M14, M15, M16, M19, M22, M23)				
591	11165107	ID BLOWER SHIELD				

## Heat Exchanger/Manifold/Gas Valve



## Heat Exchanger/Manifold/Gas Valve

	Part No:	Description:	Ref. Part No: No: Description:
Imag	e 1:		Image 1:
11	20165703S	IGNITOR	321 11072203 ORIFICE SHIELD (M12, M13, M14, M15, M16, M1
21	B1282628	GAS VALVE (36G)	M18, M19)
31	10716003	ORIFICE (QTY 2)	321 11072204 ORIFICE SHIELD (M20, M21, M22, M23)
41	0130F00010	FLAME SENSOR	371 20162903 PRIMARY LIMIT-BLUE (M4, M5, M6, M7, M8, M9, M10, M11, M17, M18, M19)
51	10123533	MANUAL RESET LIMIT	371 20162904 PRIMARY LIMIT-TEMPERATURE CONTROL (M1,
61	20196401	MANIFOLD - 2 BRNR (M1, M2, M3)	M2, M3, M12, M13, M14, M15, M16)
61	20196402	MANIFOLD - 3 BRNR (M4, M5, M6, M7, M8, M9, M10, M11)	<ul> <li>371 20162906 PRIMARY LIMIT-WHITE (M20, M21, M22, M23)</li> <li>381 20197312 PRESSURE SWITCH-LIGHT BLUE (M1, M9, M17)</li> </ul>
61	20196403	MANIFOLD - 4 BRNR (M12, M13, M14, M15, M16,	381 0130F00002P PRESSURE SWITCH-OLIVE (M16)
		M17, M18, M19)	381 20197310 PRESSURE SWITCH-ORANGE (M12, M20)
61	20196404	MANIFOLD - 5 BRNR (M20, M21, M22, M23)	381 0130F00004 PRESSURE SWITCH-RED (M4, M18, M19)
71	10735102S	BECKETT BURNER (QTY 2)	381 0130F00001P PRESSURE SWITCH-SUNGOLD (M2, M3, M5, M6
81	0257F00038P	HEAT EXCHANGER ASSY 2B (M1)	M7, M8, M10, M11, M13, M14, M15, M21, M22, M2
81	0257F00148	HEAT EXCHANGER ASSY 2B (M3)	Expanded Model Nomenclature
81	0257F00040P	HEAT EXCHANGER ASSY 3B (M9)	M1 - GKS90453BXAA
81	0257F00150	HEAT EXCHANGER ASSY 3B (M11)	M2 - GKS90453BXAB
81	0257F00172S	HEAT EXCHANGER ASSY 3B (M4, M6, M7)	M3 - GKS90453BXAC
81	0257F00181	HEAT EXCHANGER ASSY 3B (M8)	M4 - GKS90703BXAA
81	0257F00152	HEAT EXCHANGER ASSY 4B (M19)	M5 - GKS90703BXAB
81	0257F00173S	HEAT EXCHANGER ASSY 4B (M12, M14, M15, M16)	M6 - GKS90703BXAC M7 - GKS90703BXAD
81	20418617	HEAT EXCHANGER ASSY 4B (M17)	M8 - GKS90703BXAE
81	0257F00174S	HEAT EXCHANGER ASSY 5B (M2, M5, M10, M13, M18, M20, M21, M22, M23)	M9 - GKS90704CXAA
91	20190410	BURNER BRACKET 2B (M1, M2, M3)	M10 - GKS90704CXAB
91	20190411	BURNER BRACKET 3B (M4, M5, M6, M7, M8, M9,	M11 - GKS90704CXAC
٠.	20.00	M10, M11)	M12 - GKS90904CXAA
91	20190412	BURNER BRACKET 4B (M12, M13, M14, M15, M16, M17, M18, M19)	M13 - GKS90904CXAB M14 - GKS90904CXAC
91	20190413	BURNER BRACKET 5B (M20, M21, M22, M23)	M15 - GKS90904CXAD
131	20170801AS	FRONT COVER (M1)	M16 - GKS90904CXAE
131	20170802AS	FRONT COVER (M4, M8)	M17 - GKS90905DXAA
131	20170807AS	FRONT COVER (M2, M3)	M18 - GKS90905DXAB
131	20170808AS	FRONT COVER (M5, M6, M7)	M19 - GKS90905DXAC
131	20170901AS	FRONT COVER (M9, M10, M11)	M20 - GKS91155DXAA
131	20170902AS	FRONT COVER (M12)	M21 - GKS91155DXAB
131	20170904AS	FRONT COVER (M13, M14, M15, M16)	M22 - GKS91155DXAC
131	20171001AS	FRONT COVER (M17, M18, M19)	M23 - GKS91155DXAD
131	20171001AS 20171002AS	FRONT COVER (M20, M21, M22, M23)	
141 141	0154F00000P 0154F00001P	COIL GASKET (M1, M2, M3, M4, M5, M6, M7, M8)  COIL GASKET (M9, M10, M11, M12, M13, M14,	
141	0154F00002P	M15, M16)  COIL GASKET (M17, M18, M19, M20, M21, M22, M23)	
161	M0326804	M23) TUBE PLUG (QTY AR)	
321	11072201	ORIFICE SHIELD (M1, M2, M3)	
321			
J <u>Z</u> I	11072202	ORIFICE SHIELD (M4, M5, M6, M7, M8, M9, M10, M11)	

